

STERI-PRIME SP40

FEATURES AND BENEFITS

- Anti-Viral ISO21702:2019
- Anti-Bacterial ISO22196:2011
- Durable and wipeable
- Matt finish
- Excellent opacity

PRODUCT DESCRIPTION

SteriPrime is a high opacity matt emulsion paint, it is easy to apply with low spatter. SteriPrime is also quick drying with good coverage, ideal for new plaster. With the additional hygiene benefit providing Anti-Viral and Anti-Bacterial efficacy.

TYPICAL PHYSICAL FEATURES

PROPERTY	STERICOAT SP40
Colour	Brilliant White and Magnolia, other colours may also be available
Dry film appearance	Matt
Application	Brush and roller
Spread rate	Up to 13m ² per litre depending on surface texture and porosity
Wet film thickness	76 micrometres at 13m ² per litre
Dry film thickness	19 micrometres at 13m ² per litre
Dry - touch dry	2 hours @20°C Recoat possible after 2-4 hours
Pigment	Titanium Dioxide, coloured pigments and extenders
Binder	Vinyl acetate copolymer
Solvent	Water
Volume solids	30% White, other colours will vary
VOC Content	EU limit value for this product (cat.A/a): 30 g/l (2010) This product contains max. 2 g/l VOC
Anti-Viral ISO21702:2019	98.34% 1.78 R [R=(Ut-Uo)-(At-Uo)] Coronavirus (Feline Munich Strain)
Anti-Bacterial ISO22196:2011	99.99% >4 R [R=(Ut-Uo)-(At-Uo)] E. Coli 99.99% >4 [R=(Ut-Uo)-(At-Uo)] MRSA

PREPARATION

New surfaces

All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Powdery, polished plaster or dense surfaces should be primed or stabilised. Porous surfaces should be 'mist' coated by diluting with up to 40% clean water by volume.

Previously painted surfaces

All surfaces must be sound, clean, suitably dry and free from anything that will interfere with the adhesion of the materials to be applied. Remove all loose and flaking or suspect material to a sound surface. Prime or Stabilise as required.

COATING SYSTEM

Apply two coats over primed, mist coated or previously painted surfaces. Where a large colour change is being undertaken and extra coat may be required.

APPLICATION

Stir well before use. Apply by good quality brush or roller. A medium pile roller is best for smooth plaster surfaces. For airless spray (dilution may be required). For further information follow the spray manufacturer's guidelines.

CLEANING

Return surplus material to container. Wash equipment with clean water immediately after use.

HEALTH AND SAFETY

Please refer to the Safety, Health and Environmental Information on the container. Take special precautions during the surface preparation of pre 1960's painted surfaces as they may contain harmful lead. For further information contact our Customer Relations Team. When preparing all surfaces avoid the inhalation of dust and/or metal particles. Wear a suitable facemask. Material Safety Data Sheets for this and all other SteriCoat™ Paints products are freely available from the place of purchase or the address below. Store in secure dry conditions inaccessible to children or animals. Containers should be kept closed during storage. Do not empty into drains, watercourses or access routes to septic tanks.

GENERAL INFORMATION

Apply all products in accordance with BS 6150: Code of practice for painting of buildings and BS 8000: Part 12: 1989 Code of practice for decorative wallcoverings and painting. Under normal and frost-free conditions this product will remain usable for up to two years if stored correctly and unopened.

**For all other support
please get in contact
with us:**

www.stericoat.co.uk
+44(0) 333 3355499



The information provided is given in good faith on the basis of practical experience and extensive laboratory tests. Many factors beyond Chem X's control and uniquely within the user's knowledge and control can affect the use and performance of a Chem X product in particular application. User is solely responsible for evaluating the Chem X product and determining whether it is fit for a particular purpose and suitable for user's method of application. Chem X makes no other warranties or conditions, express or implied, including, but not limited to, any implied warranty or condition of merchantability or fitness for a particular purpose or any implied warranty of non-infringement or any implied warranty or condition arising out of a course of dealing, custom or usage of trade. IF the Chem X product does not conform to this warranty, then the sole and exclusive remedy is, at Chem X's option, replacement of the Chem X product or refund of the purchase price. Please recycle. Printed in the United Kingdom